

Wi-Fi
connection
or mobile data
tariff required

emporia SMART.7 mini

DEUTSCH · 01
ENGLISH · 63
FRANÇAIS · 125
ITALIANO · 187
NEDERLANDS · 249

i *Google, Android, Google Play*, Google Pay and other marks are trademarks of Google LLC.*

** also known as Play Store*

Dear Valued emporia Customer,

What's life about? This is the question we focused on at emporia when developing and designing this smartphone for you. Yes, you've read that correctly. We didn't start by asking how much RAM and ROM and how many megapixels and milliampere hours the device should have. We initially put those questions on the back burner and ultimately passed them to our engineers to answer later on.

We were much more interested in what life is actually about. Safety, health, joie de vivre, sustainability, love, solidarity ... These are the things that really matter in life.



And it's these things that we've built this smartphone around. It can and will assist you in all these important areas. »It will help me with love?« I hear you ask. It will indeed. Won't it be nice to be able to send your partner a kiss by WhatsApp when they're in another room? Now wondering how this smartphone can increase your joie de vivre?

You'll receive a short video of your grandchild and it'll be as if the sun is shining even if it's actually raining! Safety? It's great that there's a Panic button with emergency function on the back of the phone, just in case you happen to fall off your e-bike, for example.

We've found answers to the important questions in life.
I hope your new emporia smartphone brings you plenty of joy!

Eveline Pupeter
Owner and Managing Director

Notes on this user guide

- This guide contains helpful notes and tips, which are indicated as such by this symbol: 
- Warnings are indicated by this symbol: 
- Lots of chapters contain a QR code, which will take you to more information on the chapter's topic on the emporia website.

QR scanner

This application enables you to read QR codes. Open the **QR scanner** app or select the **QR scanner option** in the **Camera** app
(see page 103)



CONTENTS

1. Preparation	68	4. emporia interface	80
1.1 An overview of your smartphone ..	68	4.1 Home screen.....	80
1.2 Box contents	69	4.2 App screen.....	83
1.3 Inserting a SIM card and a memory card	70	4.3 Personal screen	84
1.4 Charging the battery	70	4.4 emporia Smartcover.....	85
1.5 Turning on the phone	72	5. Basic functions	87
1.6 Entering a PIN code	72	5.1 Phone calls.....	87
2. Using the phone for the first time	73	5.2 Contacts	88
2.1 Basic Android and Google settings	73	5.3 Messages	91
2.2 Starting the emporia app.....	75	5.4 Info centre	93
2.3 Switching between the emporia and Android interfaces ...	76	5.5 Photo album	94
3. Using the phone	77	5.6 Camera	95
3.1 Battery-saving mode and locking the screen.....	77	6. Other emporia apps	96
3.2 Buttons on the phone	78	6.1 Torch	96
3.3 Keys on the screen	79	6.2 Silent mode.....	96
3.4 Keyboard on the screen	79	6.3 Alarm clock	97
		6.4 Calendar.....	98
		6.5 Weather	99
		6.6 Internet.....	100

6.7	E-Mail.....	101	8.	More settings	112
6.8	Calculator.....	102	8.1	Audio profiles.....	112
6.9	Magnifier.....	102	8.2	Wallpaper.....	113
6.10	QR scanner.....	103	8.3	Date and time.....	113
6.11	Touch Trainer.....	104	8.4	Language and input.....	113
6.12	emporiaCOACH.....	104	8.5	emporia keyboard.....	113
6.13	Google apps.....	105	8.6	Display.....	114
7.	Establishing connections	106	8.7	Security settings.....	114
7.1	Using a Wi-Fi connection.....	106	8.8	System updates.....	115
7.2	Bluetooth.....	108	8.9	Battery saver and battery protection.....	115
7.3	NFC connectivity.....	109	8.10	System settings.....	115
7.4	Wi-Fi hotspot.....	110	8.11	Accessibility.....	116
7.5	Using a Mobile Data Connection..	110	8.12	Favourites function.....	117
7.6	Flight mode.....	111	9.	Emergency call function	118
7.7	Location.....	111	10.	Appendix	120
7.8	Flash notifications.....	111			
7.9	Connecting to a PC to transfer data.....	112			

1. PREPARATION

1.1 An overview of your smartphone



1 Front camera

2 Receiver

3 Touchscreen

4 Charging contacts

5 Microphone

6 USB/Headset port

7 Loudspeaker

8 Card slot

for SIM card and SD card

9 Camera lenses
with torch and flash

10 Panic button
with favourites function

11 NFC module (internal)

12 Volume buttons

13 On/Off button
with fingerprint sensor

1.2 Box contents

! *The contents of this package are not suitable for young children and include small parts that can be swallowed.*

- Smartphone
- SIM ejector tool
- USB charging cable
- User guide

› **What to do if a part is defective or missing**

Please contact the **emporia Service Centre**. (see page 120)

› **Not included in the scope of delivery**

• **SIM card**

The SIM card is a chip card that you need to insert into the phone. You will only be able to place calls once you have done this. Your network operator will provide you with the card and the codes belonging to it (PIN and PUK) when you buy a mobile contract. Always choose a tariff with a data package when using a smartphone.

• **Memory card** (*increases storage capacity*)

A memory card is a chip card that will increase your smartphone's storage space. Inserting one will enable you to store more photos and install more apps. You can purchase these cards from electronics stores.



How do I insert a SIM card and memory card?

Scan QR code for more details

- **Headset**

Suitable headsets are available from <https://www.emporiamobile.com> and electronics stores.

- **Mains plug**

Use a USB C power delivery charging adapter with a minimum output of 15 watts or more for charging. You can obtain these from an electronics store, in the web shop at www.emporiamobile.com or from the **emporia Service Centre**.

1.3 Inserting a SIM card and a memory card

- Release the card slot by inserting the SIM tool into the small hole in the card slot.
- Insert the card with the gold contacts facing down.
- **If you wish**, you can insert a memory card into the slot with the gold contacts facing down.
- Put the smartphone down with the screen facing up. Now push the card slot all the way back into the smartphone.



What to do if you've used all your storage space.
Scan QR code for more details

i Only use nano SIM cards in this device. If your SIM card is a different size, your network operator will swap it for you.

i Only use a memory card that is compatible with this phone, such as a microSD® or a microSDHC® card. If you use an incompatible SIM card or memory card, you may damage the phone, the card itself or the data stored on the card.

1.4 Charging the battery

! Only use chargers that are permitted for this smartphone. You can find suitable original emporia accessories in the emporia webshop at <https://www.emporiamobile.com/en/collections/accessories>

i Before using the unit for the first time or if the unit has not been used for a long time, the battery must be charged. The charging time depends on the charger used and takes approximately 2-4 hours.

> Charging with the charging cable

- Use a standard mains plug with a USB-C socket that you have at home.
- Insert the USB connector into the phone's USB port.
- Then plug the cable's mains plug into a wall socket.

i *To avoid contact faults with the USB connector, only use the charging cable supplied with the phone for charging.*

> Charging via a computer

Plug the phone into a USB port on your computer. If necessary, disconnect the USB cable from the mains plug to do this.

i *Charging your phone via a computer will take longer than charging it via the mains.*

> Battery indicators on the phone

- When the battery is empty:
The phone will beep and a warning will appear on the screen. The battery icon is red and the LED flashes.
- When the battery is being charged:
The battery icon is shown filling up and the LED is red.
- When the battery is fully charged:
The battery icon is full and the LED is green.
You can now disconnect the charging cable from the phone and then unplug the cable from the wall socket.

i *In **Settings > Battery**, you can view the remaining battery life and current charge level, and can close applications to extend the battery life.*



How do I charge the battery correctly?

Scan QR code for more details

1.5 Turning on the phone

- Press and hold the on/off button for at least two seconds.
- The emporia logo will appear on the screen and a melody is played.

i When you turn your phone on the first time, the start-up process can take up to two minutes. The emporia logo will be on the screen when this is happening. Please do not interrupt this process.

1.6 Entering a PIN code

Enter the four-digit PIN code for your SIM card when asked to do so and confirm the entry.

i You can change or turn off your PIN code in **Settings > Security & privacy > More security & privacy > SIM lock**.

! You have a maximum of three attempts to enter your PIN code correctly. If you enter the wrong number three times in a row, you will only be able to unblock your SIM card with your PUK code. You will find your PIN code and PUK code in the documents supplied with your SIM card by your network operator.



What does my smartphone need in order to work?

Scan QR code for more details

2. USING THE PHONE FOR THE FIRST TIME

Using the phone for the first time

2.1 Basic Android and Google settings

When you use your smartphone for the first time, you need to select a number of settings.

› **Selecting a language**

- Tap on the pre-selected language.
- A list showing all the available system languages will then appear.
- Select the language you want to use to operate your smartphone.

› **Starting Android settings**

Now tap on **START** to define a few required settings for the Android operating system.

› **Connecting to a Wi-Fi network**

If possible, establish a Wi-Fi connection, so that future essential updates and downloads don't use your mobile data.

i *Read more about this in chapter »Using a Wi-Fi connection« (Seite 106)*

› **Copying apps and data**

Your smartphone will now check whether any updates for the Android operating system are available and, if there are any, install them automatically.

Used a smartphone before? In the next step, you can install apps and data from your old smartphone. To do this, tap on **NEXT**, select a transfer method and follow the instructions on the screen.

If this is your first smartphone or you don't want to transfer any data, tap on **DON'T COPY**.



Setting up a Google account
Scan QR code for more details

› **Setting up a Google Account**

- In the next step, you will be asked to sign in with your Google Account. Enter your Gmail address and the password for the account to do this, or create a new Google Account if you don't yet have one.
- Now you can select settings regarding the security and storage of Google services. Read through the pre-selected settings carefully and disable any individual functions you don't require. Then tap on **ACCEPT**.

› **Selecting a search provider**

Select the Internet search engine provider whose service you want your phone to use when carrying out a search query.

› **Protecting your smartphone**

Now select a screen lock, so that your phone cannot be operated by anyone not authorised to do so.

i *You can also protect your smartphone using a fingerprint. If you prefer, you can add these settings later on in **Settings > Security & privacy > Device unlock > Fingerprint**.*

- Also choose whether the code has to be entered when the device is first started.
- Enter your chosen code.
- Enter the code a second time to ensure you haven't made any typing errors and then confirm it.

› **Enabling Google Assistant**

Now you can install the full version of Google Assistant. Please note that you are granting Google a wide range of permissions if you do this.

- Tap either **ACTIVATE** or **NO THANKS**.
- If you want to control Google Assistant using voice commands, set up Voice Match by tapping on **I AGREE** and following the instructions on the display.



How does the voice assistant work?

Scan QR code for more details

› **Setting up Google Pay**

If you would like to link your Google Account to a payment facility, tap on **ADD CARD** and enter the required details.


i You can skip this setting for now and add it in your Google Account later on.

› **Changing the wallpaper and font size**

Finally, you can personalise your smartphone's wallpaper and adjust the font size. These settings will be applied to all your phone's system, but not to the emporia app. Now complete the installation process.

2.2 Starting the emporia app

When you have completed the Android and Google settings, you will see the Android home screen. Tap on the emporia icon.



› **Legal notices**

Agree to the terms and conditions, the data privacy policy and the app permissions for the emporia app. To do this, check the box next to **»I have read and I agree to all of the above.«**

Confirm this by tapping on **NEXT**.



App tip: Google Pay
Scan QR code for more details




STARTING emporia
Scan QR code for more details

› **Setting the emporia app as the home screen**

Select the following settings to make your smartphone start with the emporia interface.

- Tap on **NEXT**.
- Tap on **emporia**
- Tap on **Set as default**



› **emporia app registration**

Enter your name, age group, gender and email address and confirm these details by tapping **NEXT**.

- Then tap on **FINISH** to complete the set-up process for the emporia app.
- Your smartphone will now start up with the emporia interface every time.

› **Concluding the set-up process**

- › A notification will appear in the **Info centre** if any of the installation steps have been skipped.

› **New apps after installation**

The emporia app includes a whole bundle of applications. You will therefore now see a number of new icons on

your smartphone, which represent the following functions:


- On the emporia home screen:
Phone, Messages, Photo album and Info centre
- You will find all other emporia apps on the **Favourite apps** page.

2.3 Switching between the emporia and Android interfaces

› **Disabling the emporia interface**

You can use the default Android interface on this smartphone if you wish.

- To disable the emporia interface, open **Settings > Apps > Default-apps > Start app**.
- Then select **Quickstep** as the default start app.



Switching interfaces
Scan QR code for more details

3. USING THE PHONE

› Restoring the emporia interface

If you've deleted the link for "Start emporia" on the home screen, you can restore the emporia interface by doing the following:

- Open **Settings > Apps > Default-apps > Start app**.
- Then select **emporia** as the default start app.

› Disabling the emporia keyboard

- Open **Settings > System > Language and input > Virtual keyboard**
- Disable the emporia keyboard.
The phone will now use the Android keyboard.

i In **Standard apps**, you can also specify which app you want to use for SMS messages and which browser you want to be your default browser.

3.1 Battery-saving mode and locking the screen

If you don't use your phone for a certain period of time, the screen will switch to battery-saving mode and go black. You can reactivate the screen by pressing the on/off button briefly.

Locking the screen can also protect your phone from unintentional input on the touchscreen.

› Locking the screen manually

- Press the on/off button briefly.
- The screen will go black and lock, and the phone will beep. The screen is now protected from any unintentional input.

› Setting the screen to lock automatically

You can choose from the following device security options in **Settings > Security & privacy > Device unlock**:

• Screen lock:

- None
- Swipe
- PIN: Enter a code of your choice.

• Fingerprint:

You can save up to five fingerprints.

3.2 Buttons on the phone


› On/Off button with fingerprint sensor


- Hold the on/off button down for at least 2 seconds to turn the phone on or off.
- Press this button briefly to wake the phone from or put it into battery-saving mode.
- If you've selected and set up the fingerprint security function, this button will act as the fingerprint sensor.
- Place one of the fingers whose prints you've stored on the button to wake the phone from battery-saving mode.


› Volume buttons

The volume buttons on the side of your phone allow you to adjust the volume, mute the phone when it is ringing or mute the alarm clock.

1 Audio profiles for ringer volume:


 Ringer sounds for calls and notifications

 Calls and notifications trigger an alarm accompanied by vibration

 Alerts for calls and notifications are muted

2 Slide controller for media volume

3 Volume control button:
Slide controller for **Media volume, Call volume, Ring and notification volume** and **Alarm volume**



 You'll find the *emporia silent mode* in *Quick settings* (see page 96).

› Panic button with favourites function

This button on the back of the device can be assigned various functions (see page 116):

1. Open **Settings > Favourites function**.
2. Select one of the options:
 - **Emergency call** (Factory selected)
 - **Torch**
 - **Silent Mode**

- **Camera**
- **Favourite app**
- **No function**

3.3 Keys on the screen

> Home

- This button will take you back to the home screen any time if you tap it briefly.
- If you tap and hold this button, the Google Assistant will be activated.

> Back

This button allows you to undo your last action.

> Menu

Tapping this button will display all your recent apps, i.e. those that are currently active, in windows alongside each other.

- To switch to one of the apps displayed, tap on it briefly.
- Close an app by swiping the image of the app up.



Using the touchscreen


Scan QR code for more details

3.4 Keyboard on the screen

Whenever text input is necessary and you tap on the text input field, the software keyboard will automatically appear on the bottom half of the screen.

There are several different keyboards, which you can access by tapping the grey buttons:

- 1 Keyboard with capital letters
- 2 Keyboard displaying numbers and characters
- 3 Keyboard displaying symbols and emoticons
- 4 Standard letter keyboard
- 5 Standard letter keyboard



1

2

3

4

5




Speech to text

Scan QR code for more details

4. EMPORIA INTERFACE

4.1 Home screen

The home screen is the starting base for all your smartphone's operations. You can press the home button to call the home screen up and return to the starting base at any time.



The home screen consists of the following elements:

› 1 Wallpaper

The wallpaper is a decorative background image and can be set according to your personal preferences.

The time, date and weather are inserted on top of the image. To change any of these settings, tap and hold the screen for a few seconds.

2 Below the wallpaper, there are four buttons which have been preset with the most important functions:

- **Phone calls and contacts**
(see page 87)
- **Messages** (see page 91)
- **Photo album and Camera**
(see page 87)
- **Info centre** (see page 93)

i To change the function assigned to one of these buttons, tap and hold the button for a few seconds.



emporia interface
Scan QR code for more details

> **3** **Toolbar:**



Battery icon: Indicates the battery's charge status. If you tap on the icon, the battery's charge status is indicated as a percentage.



Alarm clock: The alarm clock is on.



Silent mode: The silent audio profile is on.



Flight mode: Flight mode is on.



Signal strength: Provides information about the reception. Tapping on it will open the extended display panel, which can show the following symbols:



Indicates **roaming** status; additional costs may be incurred when you're connected to another network



Wi-Fi: A connection to a Wi-Fi network is established.



Wi-Fi: A connection to a Wi-Fi network is not established.



GPS is on



GPS is on and has detected your position



Headset: Headset or an external loudspeaker is plugged in.



Call forwarding: Call forwarding is activated.



NFC is on.



Bluetooth is on.




A **Bluetooth** device is connected



Wi-Fi hotspot: The smartphone is available as a Wi-Fi hotspot for other devices.

› **4 Quick settings:**

Tapping on the gear icon  will open **Quick settings**. Here, you have an overview of your smartphone's most important settings and can turn functions on or off quickly.

- **Torch** (see page 96)
- **Alarm clock** (see page 97)
- **Silent mode** (see page 96)
- **Wi-Fi** (see page 106)
- **Bluetooth** (see page 108)
- **NFC** (see page 109)
- **Wi-Fi hotspot** (see page 110)
- **Mobile data** (see page 110)
- **Flight mode** (see page 111)
- **Location** (see page 111)
- **Flash notifications** (see page 111)
- **Favourites function** (see page 116)
- **Smartcover** (see page 85)
- **Fingerprint** (see page 114)
- **Audio profiles** (see page 112)
- **Wallpaper** (see page 113)
- **Date and time** (see page 113)
- **Language and input** (see page 113)
- **emporium keyboard** (see page 113)
- **Display** (see page 114)
- **Security settings** (see page 114)
- **System updates** (see page 115)
- **System settings** (see page 114)

4.2 App screen

On the app screen, you have access to all the apps that are installed on your phone.


You can place the apps that you personally intend to use most directly on this screen.

Tap and hold one of the buttons for a few seconds and select your chosen function from a list.

The button in the bottom right-hand corner, **All apps**, opens a list that displays all the apps available on the smartphone.

› Installing apps

Under **Suggested Apps** you will find a selection of practical applications to download or use Google Play.



› Deleting apps

- Open **All apps** on the app screen
- Swipe to the end of the list.
- Tap on **Delete**. Deletable apps are now marked with a box.
- Tap on the box of the app you want to delete.
- Now tap on **Delete** in the top left-hand corner.
- Confirm the deletion process by pressing **OK**.



Google Play
Scan QR code for more details

4.3 Personal screen

You access the personal screen by swiping a finger across the screen from left to right.

You can assign functions to all the buttons on the personal screen according to your individual preferences.

› Favourites


You can save contacts that you intend to call often here.

- Tap on a contact button.
- The list of your contacts will open. Select a contact from the list by tapping on it.
- This contact will now be displayed as a favourite. If you tap on the favourite, the phone will call the contact immediately.

i *This function can be used even when the Smartcover is closed.*

› My phone number:

Your own phone number will automatically be displayed here. If you tap on it, you can do the following with the number:



- Send it to someone by email
- Text it to someone
- Copy it
- Edit it

i *Depending on your network provider, it is sometimes not possible to store your own phone number.*

› Voicemail:


Here you can access your voicemail and specify settings for it:

- Tap on the button briefly to listen to your voicemail.
- Tap and hold your finger on the screen to go to the settings for your voicemail.

› Emergency call

Here you can specify settings for the emergency call function:

Read more about this in chapter »9. Emergency call function« of page 118.

- Save up to five emergency contacts.
- Enable the  button on the back of the phone.
- Start an emergency call.

4.4 emporia Smartcover

i *The Smartcover is not included in the scope of delivery of the emporiaSMART.7mini. It can be purchased as an accessory at www.emporiamobile.com.*

The emporia Smartcover is a unique accessory: a protective case in book format. It is equipped with four buttons on the front that can each be assigned a function. This means the functions you have selected for these buttons can be used even when the cover is closed.

Another great advantage of the



Smartcover is that the buttons cannot be pressed accidentally and cause you to make "pocket calls", because they'll only respond to the capacitive voltage of your skin.

› Attaching the Smartcover

- Place your smartphone in the Smartcover. The cover will stick to the back of the smartphone thanks to built-in magnets.
- Close the front of the cover using the magnetic flap. The screen will now automatically adapt to fit the Smartcover.

i *If the smartphone is in battery-saving mode, activate the screen by pressing the on/off button.*

! *The emporia smart cover is equipped with strong magnets. Make sure that credit cards or similar items are not kept in direct contact with the smart cover.*








Smartcover

Scan QR code for more details

› **Linking the function buttons**



- From the home screen, **open the following: Quick settings > More settings > Smartcover.**
- You will see three predefined settings available, which are assigned to the buttons as follows:

Functions: Green key , red key , torch  and camera 




Favourites: Four contacts  that you have linked on the personal screen as favourites


Off: No functions are assigned to the function buttons.

› **Using the function buttons**






- The four function buttons will each display the symbol representing their respective predefined setting.
 - When you press one of the buttons, the screen will adapt to display the available options.
-  **Green key** – will confirm a highlighted selection, answer incoming calls, and activate the phone function and phone book
 -  **Red key** – will take you one step back,


decline incoming calls and end an ongoing call


-   **Arrow keys** – allow you to move between items available in a list
-  **Camera button** – turns the camera function on

 *The vertical cut-out below the function buttons indicates the progress when the phone is charging.*

› **Options for the camera:**

-  Flash function
-  Record video
-  Stop recording video
-  Take photo
-  Torch button

 *You can open the Smartcover at any time. If you do this, your smartphone will automatically switch to using the whole screen for the current function.*

 *If the alarm clock is enabled and rings, you can switch it off by pressing the red key or activate the snooze function by pressing the green key.*

You can select the following functions (apps) on the home screen:

- **Phone calls and phone book**
- **Messages**
- **Photo album and camera**
- **Info centre**

» **Phone calls and contacts**

This application enables you to place calls and manage your contacts.



5.1 Phone calls

There are three ways of entering a phone number to make a call:

- **Contacts:** Select a contact from the list and tap on the name.
- **Keypad:** Enter the number using the keypad and then press **Call**.
- **Recent calls:** Select a contact from your list of recent incoming and outgoing calls. Missed calls are displayed at the top of the list and are marked.

» **Accepting or rejecting a call**

If you are called, you can accept the call by tapping the green **Answer** button briefly or reject the call by tapping the red **Decline** button.



How do I know when my smartphone is ready to use?
Scan QR code for more details



Google Phone
Scan QR code for more details

› **Options during a phone call**

- Keypad
- Mute
- Speaker
- More
 - Hold
 - Video call
 - Add call

› **Deleting your call history**

Select the contact, you want to delete from the list by tapping and holding it. Choose **Delete** from the popup box. Confirm the security query.



EN-88

5.2 Contacts

This app displays all the contacts available on the phone.



› **Searching for a contact**

All your saved contacts will be displayed in a list and sorted alphabetically by names. Tap on a name in the list to call the contact.

If it is taking too long to find the contact you want in the list because you've saved a large number of contacts, you can also type the first few letters of the contact into the search bar. All the contacts that begin with these letters will then be compiled in a short list.

› **Adding a contact**

1. If you want to add a new contact record, tap on **Create new contact**.
2. Enter the first name, last name and phone number, then **save** the information. You have now created a contact record for this person and can expand it by adding other details such as a contact photo, their landline number, their email address and their birthday.


› **Transferring contacts from your old phone to this smartphone**

There are several ways to transfer the contacts from your old phone to this phone:

• **Importing contacts from your SIM card**

Save all the contacts onto the SIM card while the SIM card is in your old phone and then insert the SIM card into your new smartphone.

When you insert the SIM card into your new smartphone for the first time, the contacts that are stored on the SIM card will be detected automatically. You will be asked to transfer the contacts to the phone. Once you've done this, the imported contacts will appear in the app **Contacts**.

 However, if you use a new SIM card because you have bought a new tariff for the smartphone, for example, there are other options. Your specialist retailer will be able to transfer data from your old SIM card to the new one using a SIM card reader.

• **Manage contacts with a PC**

You can also transfer the contacts from the old phone to your PC and from there back to the new phone.



› **Deleting contacts**

Open the contact you want to delete and select **Delete**.

› **Opening a contact record**

If you want to open a contact record, tap on the name or number **1**. **2** The contact record containing the contact's photo, mobile number and eventually email address and birthday will then be displayed.

If you press a symbol button, the action connected to the button will be performed. For example, tapping on the call symbol will start a call. Use the symbols **3** to perform the connected actions: **Call**, **Text** and **Video**.




› **Editing a contact record**

Tap on the **Star** symbol **4** to define the contact as favourite.

Tap on the **Settings** symbol **5** to find more actions referring to the contact record.

If you want to change existing details for a contact, tap on the **Pencil** symbol **6**. You can then tap on the phone number, for example, change it and save the new number.


› **Tip:** Before closing the contact record again, press the "Save" button, so that all your changes are saved.



› **Block unwanted numbers**

Open the relevant contact in the call list and tap **Block numbers**.

› **Numbers for internet calls and apps such as WhatsApp must be blocked separately in the respective app.**



Importing contacts
Scan QR code for more details

5.3 Messages

This application enables you to send and receive text messages (SMSs) and multimedia messages (MMSs).



› Sending a message

First select the contact you want to write the message to.

Open the **Messages** app.

Open a contact from the list of recent chats.

Or tap on the "**Start chat**" field and enter the recipient's name or number in the "**To:**" input field.

› Writing a message

Enter the text using the keyboard on the screen.

If the on-screen keyboard doesn't open automatically, tap on the field "**Text message**".

› Reading a message

A notification will inform you when you have received a message.

Open the **Messages** app and find the new message on top of the list of chats.

› Drafting a message

You can switch to another application in the middle of writing a message any time. When you return to contacts, the message you have started will be displayed.



emporia app: Messages
Scan QR code for more details

› **Deleting the chat or a message**

• **You want to delete the whole chat?**

1. Open the chat you want to delete.
2. Tap on the **Options** menu symbol (three dots) in the top right corner.
3. Choose "**Delete**" and confirm the popup question.

• **You want to delete a single message from the chat?**

1. Open the chat.
2. Tap and hold the message you want to delete until it is highlighted.
3. Tap on the waste bin symbol.
4. Confirm the popup box by choosing "**Delete**".

› **Forwarding a message**

Open the message sequence that contains the message you want to forward.

Tap and hold the message you want to forward until it is highlighted. Tap the **Options menu** icon (three dots) in the upper right corner. Select 'Forward' and then 'New message'.

The text will be copied into a new SMS message.

Here you can edit the text if necessary, add the recipient and then send the message.



SMS or messaging apps?
Scan QR code for more details



Google Messages
Scan QR code for more details

› **What is the difference between an SMS, an MMS, email, a messaging app and a notification?**

- **SMS** (Short Message Service) is a format for short messages and only allows text in messages to be sent.
- **MMS** (Multimedia Messaging Service) is a type of SMS that allows small amounts of data such as photos to be sent in addition to text.
- **Email** is a messaging system that people are generally familiar with from using a computer. You need an email address to use it.
- **Messaging apps** are apps that were developed to be used on a smartphone. There are lots of different messaging apps, one being WhatsApp.
- **Notifications** are small pieces of information that your smartphone uses to tell you about activities on the phone.

5.4 Info centre



This application provides you with an overview of all the notifications you have received regarding various apps. These notifications include missed calls, new messages, updates to installed apps, etc.

› **Opening notifications**

Open the **Info Centre** and tap the message you want to read. When the notification has been read, it no longer appears in the list.

› **Deleting notifications**

A notification will normally disappear as soon as you have tapped on it. Regardless of this, however, you can also delete the entire list by tapping on **Delete all**.



Whatsapp

Scan QR code for more details



What are updates and what do I have to do with regard to them?

Scan QR code for more details

5.5 Photo album



This application enables you to view and manage photos, and also activate the camera and take photos.

The photo album displays all your photos as thumbnails and sorts them chronologically by month. You can adjust the number of photos displayed at a time using the + and – buttons, which are shown briefly when you open the photo album.

› Viewing a photo

Tap on a photo in the photo album to open it.

Tap on the photo briefly to make the following buttons visible:



emporia app: Photo album
Scan QR code for more details



Managing photos using Google Photos
Scan QR code for more details

◀ and ▶: Move to other photos

🗑️: Delete the current photo

★: Mark the current photo as a favourite.

Options: Delete, Set as wallpaper, Share, Zoom in, Zoom out and Rotate (If a video is selected, only **Delete** and **Share** are available.)

i Zoom into the image by tapping it twice.

› Sending and copying a photo

Open a photo and select **Options**.

Selecting **Share** allows you to send the photo to others by Bluetooth, email, MMS and other applications.

You can copy the photos to a PC when you establish a USB cable connection.

i If you want to send more than one photo at the same time, tap and hold your finger on one photo on the photo album overview screen. You can then select multiple photos and share or delete them in one go.

- i** Do you want to know where a photo is stored? Tap and hold a thumbnail in the photo album for a few seconds and then select **List**. The folder in which the photo is stored on your phone will appear.

5.6 Camera

To activate the camera, select **Take picture** in Photo album.



Or open the **Camera** app in **All apps**.

Press the camera icon on the screen to take a photo.

- i** This function can be used even when the Smartcover is closed.

> Enlarging or shrinking the image section (zooming)

You can crop the image in two ways:

- Zoom in and out using **+** and **-**: Tap the **+** button to bring the subject closer. The **-** button will shrink the image again.
- Zooming with two fingers

> Selecting flash mode

Tap on the  flash icon and choose between **Flash on** , **Flash off**  and **Auto flash** .

> Options for the camera:

Front camera / Back camera, Video mode / Photo mode, Effects, Magnifier, QR scanner, Picture size / Video quality, Filter and **Storage**

> Taking a selfie

If you want to take a selfie, open **Options** and switch from the back camera (on the back of the phone) to the **Front camera** (on the front of the phone). You will then be able to see yourself on the screen, as you would if you were looking into a mirror, and taking a good selfie will be much easier!

> Recording a video

Switch to **Video mode** in **Options**. You can use both the back camera and front camera in video mode too. Use the front camera if you want to film yourself. To start recording, tap on the red button with the film camera symbol. A stopwatch in the top left-hand corner will tell you how



emporia app: Camera
Scan QR code for more details

long you've been recording. To stop, press the red button again.

i **Camera Pro** is pre-installed. It is a second camera app that meets the demands of customers who are interested in more options and more features.

6. OTHER EMPORIA APPS

The following apps were developed by emporia and have deliberately been kept very simple. You can access them on the **Favourite apps** screen, in **All apps** and in **Quick settings**.

You can find apps with more complex functions in the **Google Play**.

6.1 Torch

Activating the **Torch** in Quick settings enables you to turn the LED on the back of your smartphone on and off.

i *This function can be used even when the Smartcover is closed.*

6.2 Silent mode

- Activate **Silent mode** in Quick settings.
- Next, enter a time at which you want **Silent mode** to automatically end and the phone to start ringing when it receives calls again.

i *Read more about this in chapter »Volume buttons« of page 78.*



The perfect smartphone photo
Scan QR code for more details

6.3 Alarm clock

› Setting the alarm clock

- Tap on **Alarm time** and enter your desired time using the numeric keypad. Save your changes. The alarm clock will now sound at the time you have set.
- Tap on **Alarm ringtone** to set the sound the alarm makes when it rings. Please note that some alarm sounds are quite loud, while others are softer and quieter.
- Adjust the **Volume** of the alarm ringtone for the alarm clock.



› Enabling or disabling the alarm clock

You can enable or disable the alarm app using the on/off button in the **Alarm app** or **Quick settings**.

› Turning off the alarm clock

When the alarm clock goes off:

- Use the **Volume button** to mute the alarm clock without turning it off.
- Tap on **Stop** to turn off the alarm clock.
- Tap on **Snooze** to set the alarm clock to go off again in 5 minutes.

i *This function can be used even when the Smartcover is closed.*

i *If the phone is turned off, the alarm is turned off as well. The alarm will therefore not sound when the phone is off.*



emporia app: Alarm clock
Scan QR code for more details

6.4 Calendar

The current month will be shown in the overview.

Today's date will be in blue.



› Entering a new event

- Tap on **New entry** and specify whether you want to enter an **Event** or a **Birthday**.
- Enter a name for the new event. This name is what the event will be shown as on the calendar.
- Now enter a time frame for the event. Today's date and the time 30 minutes from now will be entered by default.
- Tap on the date and time to change these details.
- In **Reminders**, you can specify how long before the event you would like to receive a notification.

- In **Repetition**, you can set the event you've just entered to recur daily, weekly, monthly or yearly.

Don't forget to save every event you enter and any changes you make!

› Opening and editing an event

In the month calendar overview, the days you've entered events on will be highlighted.

- If you tap on a day button, a list of all the hours of this day will be displayed.
- Events that have already been entered will be highlighted by coloured areas and labelled with the name of the event.

i *Be aware that the list is long! Some events may not be visible at first glance. Swipe up and down over the list, so that you can see events entered at other times of the day.*

- If you tap on an event, the details of the event will open and you can make changes to them.



emporia app: Calendar
Scan QR code for more details

› **Searching for an event**

- To do this, tap on **New entry** in the month overview and then on **Next event** in the list that appears.
- All your events from today's date onwards will now be listed in chronological order.
- You can of course then tap on one of these events to open all its details and also edit the event.

6.5 Weather

› **Setting up the weather app**

- Open **Weather > Settings**.
- Turn the weather function on.
- Select **Add location**.



› **Set location automatically**

If you open the app for the first time, you can allow the app to set your location automatically. Select **Yes** or **No** when prompted.

› **Set location manually**

- Enter the **Location** (your desired place) in the **Search** bar. A list of places will be displayed. Select the place you want from these.
- Select **Back** to view the weather forecast for the next few days for this location. The current temperature in this place will be shown above the date on the home screen.
- If you want to know the weather in another place, specify a new location.
- Now select the place you want the weather for and confirm your choice by tapping on the tick.



emporia app: Weather
Scan QR code for more details

6.6 Internet



> Searching for information on the internet

- Open the **Internet** app.
- The search bar is the main element of the browser. It is where you enter search terms you want to find information on. Tap in the **Search bar** to open the keyboard. Enter a **search term**.
- When the term you're looking for appears, you can tap on the **suggested word(s)** or you can finish entering your term and then confirm you want to search for it by tapping on **Go**.

- The browser will now search the Internet for **websites** related to your search term.
- The results of your search will be displayed as a list of web pages. The **domain** of each website will be written underneath the respective site's title. The domain is the address of the web page. Each web page will also be accompanied by a short description, which can help you decide whether the page will be of interest to you.
- A suggested web page will only open when you tap on its domain. Tap on **Back** to return to the list of search results.



emporia app: Internet
Scan QR code for more details

6.7 E-Mail

› **Setting up an existing email account on your smartphone**



Already using email on a computer and now want to be able to read and write emails on your smartphone? Make sure you know your account details before you begin setting up your email account on your smartphone:

- What is your email address?
- What is the password for this account?

› **Displaying newly received emails**

If you have received an email, your smartphone's LED indicator will flash and a corresponding notification will be shown in the Info centre.

Open the **Info centre** and tap on the notification to display the new email. You can also open the **Email** app in the **All apps** list and go straight to your **Inbox**.

› **Writing emails**

When you open an email app, the first screen you see will normally be the inbox. Many apps have a pencil icon somewhere on this screen. Tapping on the pencil will open the input window so you can write an email. In emporia's pre-installed app, you have to tap on the **Write email** button.



Linking an email account
Scan QR code for more details



Email inbox
Scan QR code for more details

Just as you do when writing an email on a computer, you now enter the recipient in the **To** row, enter a **Subject** and write your email in the space for text. When you've finished writing, you can also attach files such as photos before sending the email.

i The **Cc** field is for you to enter recipients you would like to receive a copy of the email. If you want to send an email to several recipients at the same time, but don't want your recipients to see each other's email addresses, put all the addresses in the **Bcc** field.

› **Displaying old emails**

Every email account is divided into various folders such as **Inbox**, **Sent emails** and **Drafts**. In the emporia email app, you can switch to other folders if you tap on the **Inbox** button.

› **Deleting an email account**

To do this, open the page in **Settings** that displays all the **Accounts** connected to this phone. Select the email account you want to delete and then tap on **Remove account**.

6.8 **Calculator**

Enter the numbers you require using the numeric keypad and connect them using one of the basic arithmetic operators. To get the answer, tap the = button, and to clear the display bar, tap **Delete**.



6.9 **Magnifier**

- Open the **Magnifier** app or select the **Magnifier** option in the **Camera** app.
- Now focus the phone on the object you want to magnify while maintaining fair distance between the phone and object. If the image doesn't automatically come into sharp focus, tap on the screen.



- Tap on the **+** and **-** symbols repeatedly until the object has reached your desired size.
- You can also use the torch symbol to illuminate the object if necessary.
- The camera continuously scans the viewfinder image until the QR code is read. If the image doesn't automatically come into sharp focus, tap on the screen.

6.10 QR scanner

This application enables you to read QR codes. Open the **QR scanner** app or select the **QR scanner option** in the **Camera** app.



i *If several QR codes are recognised on the display, tap on the arrow of the desired code.*

› Using the QR scanner

- Open the **QR scanner** app. On the screen, you will see the camera image in which a horizontal line is moving.
- Now focus the smartphone on the QR code you want to scan while maintaining a fair distance between the phone and object.



emporias app: QR Scan
Scan QR code for more details

6.11 Touch Trainer

If using a touch-sensitive screen is something completely new to you, the Touch Trainer could be a helpful game for you.

It will teach you how to **Tap**, **Swipe** and **Zoom** in and out in a fun way that involves simple exercises. Enjoy!



6.12 emporiaCOACH

The **emporiaCOACH** is a pre-installed app that offers you the opportunity to obtain new knowledge.

It will teach you the basics of the digital world in just a few steps that are easy to understand.

You do not need to be connected to the Internet to complete this course.



emporia app: emporiaCOACH
Scan QR code for more details

6.13 Google apps

In addition to the emporia apps, numerous Google apps have been pre-installed. A few examples are listed below:

- **Google Play**

This pre-installed Google app offers you access to countless apps that are available to download from the Internet.

- **Google Maps**

This pre-installed Google app enables you to use your smartphone as a navigation device. As well as the route-finding and navigation functions, it provides a variety of information about the respective location, destination and the traffic.

- **Google Assistant**

Google Assistant is a function that listens to your voice. It can search for information on the Internet for you, provide information and start apps if you give it a command.



Google services overview
Scan QR code for more details



Google Maps
Scan QR code for more details




Google Assistant
Scan QR code for more details


7. ESTABLISHING CONNECTIONS


7.1 Using a Wi-Fi connection

To set up a Wi-Fi connection, you need the name of the Wi-Fi network (network SSID) and the corresponding password.

 *If you already have a Wi-Fi network at home, you can usually find this information on the underside of the Wi-Fi router.*

› Enabling the Wi-Fi function

- Open **Quick settings** by tapping on the gear icon on the home screen.
- Activate the Wi-Fi function on your phone by tapping on the On/Off indicator button  beside Wi-Fi.
- The On/Off indicator button will now display **On**. The detail text on the **Wi-Fi** text button will now indicate that the phone has found Wi-Fi networks (**Wi-Fi networks available**).




**Internet connection
background information**
Scan QR code for more details

› Selecting and connecting to a Wi-Fi network

- Tap on the **Wi-Fi** text button **2**.

A list of available Wi-Fi networks will now be displayed.


- Tap on the network you want to connect your phone to.
- Enter the password for the network in the input field. Tap on the checkbox to display the password and check that it is correct.
- Confirm the entry by tapping on **Connect**.



› Checking your Wi-Fi connection

- The connection between your smartphone and the Wi-Fi network will be established.
- As soon as the connection has been established, the detail text will say **Connected**. The Wi-Fi network to which the phone is connected will now appear in the phone's **Quick settings** as well.

i From now on, your smartphone will automatically connect to this Wi-Fi network whenever it is within range. This will only happen, however, if the Wi-Fi function on the smartphone is enabled.



7.2 Bluetooth

Bluetooth is a wireless connection between electronic devices. It enables you to connect your phone to other Bluetooth-compatible devices such as a hands-free kit or an external speaker.

› **Turning on Bluetooth**


Open **Quick settings** and turn on **Bluetooth** in **More settings**.

› **Finding Bluetooth devices**

Tap on the text button **Pair new device**.

All the available Bluetooth devices in your vicinity will be listed.

If the device you're looking for doesn't appear on the list, it first needs to be made visible, i.e. put in pairing mode. Refer to the user guide for the Bluetooth device to find out how to do this.



Bluetooth
Scan QR code for more details

› **Coupling a Bluetooth device**

Select the device you want to connect to your phone. Usually you will have to enter a code on your phone or the Bluetooth device for the connection to be established. In most cases, this code will be 0000 or 1234. You will find information on this in the user guide for the Bluetooth device.

i *Devices that have been coupled before will be detected and connected automatically when they are near your emporiaSMART.*

› **Disconnecting a Bluetooth device**

If you want to disconnect a Bluetooth device from your phone, open the settings for the device in the paired devices list and select **Unpair**.

7.3 NFC connectivity

NFC (near-field communication) is a communication standard used to transfer data wirelessly. It enables data to be transferred between devices that are very close to each other relatively easily.

› **What is NFC used for?**

• **Contactless payment**

Payments made with an NFC-enabled mobile phone basically work in the same way as payments with an NFC-enabled bank card. You also have to install an app that will perform the payment process using NFC when you get to a till. And to make such payments possible, you have to save a payment option in the app.



NFC

Scan QR code for more details

- **Continuous blood sugar monitoring**

A small sensor that's attached to your body continuously measures your blood sugar level. The NFC connection is used to transfer this data to a device that can read it, such as your smartphone. The advantage of this over the usual blood sugar monitoring method is that you'll no longer have to prick your finger and will also be able to view continuous readings instead of just readings taken at certain moments.

- › **Turning on NFC**

- Open **Quick settings** and turn on **NFC** in **More settings**.
- The position your phone above or in line with the device you want to establish a connection with, ensuring the two NFC modules are as close to each other as possible.
- The NFC connection will then be established automatically and will normally be indicated by a visual or audible signal.

7.4 Wi-Fi hotspot

Turn your smartphone into a mobile router, so that you can connect other devices such as a laptop to the Internet when you're out and about.

7.5 Using a Mobile Data Connection

If you allow your phone to use mobile data, you can use the Internet, receive notifications, etc. any time.

- › **Enabling your mobile data facility**

- Open **Quick settings** by tapping on the gear icon on the home screen.
- Expand the list by tapping on **More settings**:

Quick Settings	Back
Torch	off
Alarm	off
Silent Mode	off
Wi-Fi emporia	on
Bluetooth	on
NFC	on
Wi-Fi hotspot	off
Mobile data	on



Wi-Fi hotspot

Scan QR code for more details

- Activate the **Mobile data** function on your phone by tapping on the On/Off indicator button beside **Mobile data**.
- The On/Off indicator button will now display **On**.

! *If your mobile network tariff doesn't include any data, you must leave the mobile data function on your phone disabled at all times, because turning it on can incur additional costs for you. If this is the case, you will have to be connected to a Wi-Fi network whenever you wish to use apps that require a connection to the Internet.*

7.6 Flight mode

Flight mode will disable all your smartphone's radio-frequency signal transmission technologies, meaning you can no longer make or receive phone calls, surf the Internet or send messages. You will still be able to use data already saved on the smartphone and apps that do not require the phone to be connected to the Internet.

7.7 Location

This function enables your smartphone's current location to be detected and is available to apps that have been granted permission to access the phone's location.

7.8 Flash notifications

Flash notifications can indicate incoming notifications by flashing the camera or screen.

! *Use flash notifications with caution if you're light sensitive.*

Quick Settings	Back
NFC	on
Wi-Fi hotspot	off
Mobile data	on
Airplane mode	off
Location	on
Flash notificati	off
Favourites function	
d)	Emergency call
Smartcover	



GPS

Scan QR code for more details

7.9 Connecting to a PC to transfer data

You can plug your emporia device into your PC and then transfer data easily. To do this, plug the USB connector end of the USB cable supplied with the phone into your PC and the other end into your phone.

- The phone will detect the connection and the following message will appear in the Info centre: **Device being charged via USB.**
- Tap on this notification.
- A pop-up window containing a list of options for how you can use the USB connection will then appear.
- Select **File transfer.** The phone will now be shown on your PC as an external storage device and you can copy files.

i *The process may differ from this description depending on your PC's operating system.*



Data transfer

Scan QR code for more details

8.1 Audio profiles

- **Media volume:**
Volume for media such as audio files and videos
- **Call volume:**
Volume for telephone conversations
- **Ring and notification volume:**
Volume for the ringtone and the notification sound
- **Alarm volume:**
Volume at which the alarm rings
- **Vibration and haptics:**
When this function is enabled, the phone will vibrate as well as ring when it receives calls.
- **Ringtone:**
Select a ringtone from the list for incoming calls.
- **Notification sound:**
Select a tone that you want to sound when your phone receives notifications.

- **Dial pad tones:**

When digits are entered using the keypad, the corresponding dial pad touch tones will sound.

- **Screen lock sound:**

The phone will make a clicking sound every time you lock or unlock the screen.

- **Touch sounds:**

A tone will also sound every time you tap the touchscreen.

8.2 Wallpaper

Select a photo from the photo album and set it as the wallpaper for the home screen.

8.3 Date and time

Here you can select settings for the date, time, time zone and the formats you would like these displayed in.

8.4 Language and input

Here, you specify the language for your phone and select settings for the **Keyboard**.

8.5 emporia keyboard

- **Input languages:** Choose whether you want the selected system language to be the only input language as well or specify manually which languages should be activated as input methods. If you choose to have more than one language activated, you will then be able to switch between your chosen languages when writing a message by holding your finger down on the spacebar.

- The following general settings can be activated for the emporia keyboard.

- **Auto-capitalisation**

The first letter of every sentence will be capitalised.

- **Vibrate on keypress**

The phone will vibrate every time a button on the emporia keyboard is pressed.



emporia keyboard


Scan QR code for more details

- **Sound on keypress**

Every press of a button on the emporia keyboard will be accompanied by a clicking sound.

- **Pop-up on keypress**

Every time a button on the keyboard is pressed, the selected letter will be shown as a pop-up.

 *Disabling the emporia keyboard (see page 77)*

8.6 Display

Select settings for the screen such as **Brightness**, **Adaptive brightness**, **Screen timeout** and **Auto-rotate screen**, among many others.

8.7 Security settings

To prevent your phone from being misused by other people, you can set a screen lock and a SIM card lock here. You can also specify how your phone will be protected when apps are installed.

- › **Fingerprint**

When the fingerprint function is activated, your smartphone can only be unlocked by you.

- **Setting up the fingerprint**

1. Open **Quick settings > More settings > Fingerprint**.
2. Enter your screen lock **PIN** or set a PIN now.
3. Read the information on setting up the fingerprint function and then select **I agree**.
4. Place a finger on the fingerprint sensor on the on/off button and follow the instructions on the screen.
5. Complete the fingerprint scanning process by tapping on **Finish**.

 *You can scan in up to five fingerprints.*

• **Unlocking your smartphone using a fingerprint**

Place one of the fingers you've scanned in on the fingerprint sensor.

This will immediately unlock the screen.

i *Protecting your smartphone is not the only thing you can use the fingerprint function for. You can also log in to apps or authorise a purchase with a fingerprint.*

8.8 System updates

This phone allows you to download the latest software for it yourself and therefore update the system and improve applications yourself.

1. Open **Quick settings > More settings > System updates**.
2. Check that the battery is at least 30% charged.
If it isn't, the download cannot start.

3. A message will appear telling you whether or not there is any new software available. If there is, select **Download** to start the update process. The bar indicates how the download is progressing.
4. Once the download has been completed, select **Update now**.
The software update will then be installed in the background. You can continue using the smartphone as normal during this process.

8.9 Battery saver and battery protection

In **Settings - Battery**, you can adjust **Battery saver** and **Battery protection**.

This increases the battery life and reduces power consumption.

8.10 System settings

Tapping on System settings will open the settings for the operating system Android 15.



System updates
Scan QR code for more details

8.11 Accessibility

Under **Settings > Accessibility**, you can optimise the device for users with visual, hearing or motor impairments or cognitive challenges.

› **Change display**

Users can adjust the display and font size, enlarge or reduce the display, change the contrast and colours (colour correction, colour inversion, dark design, text with outline) and much more.

- **Display size and text**
- **Colour and motion** (colour correction, colour inversion)
- **Magnification**

› **Voice output and talkback**

- The **Select to Speak** feature allows you to have content on the touchscreen read aloud by selecting items or pointing the camera at objects.
- **TalkBack** is a screen reader feature that helps blind or visually impaired users interact with their device.

› **Vibration & haptics**



Here, users can set the intensity and pattern of vibration for ringing, notifications and haptic feedback.

› **Switch Access**

Switch access allows you to control elements on the screen using one or more switches. External switches, keyboards or buttons on the device can be used for this purpose.

› **Accessibility Menu**

This menu provides quick access to important functions such as taking screenshots, locking the screen, opening Google Assistant, adjusting quick settings or changing the volume.

 **Tip:**  *The Empo-Bot on our website www.emporiamobile.com will be happy to help you with any detailed questions!*

8.12 Favourites function

The **Panic button** on the back of the device can be assigned various functions:

1. Open **Settings > Favourites function**
2. Select one of the available options:
Emergency call (Factory selected), Torch, Silent Mode, Camera, Favourite app (Select one of the apps listed), No function


› Use the Panic button

1. Press and hold the **Panic button** for:
 - **Emergency call** (factory selected):
 - When operating in Android mode, the Google emergency call function is started.
 - In emporia easy mode, the emporia emergency call function is started.
 - **Torch:** activates the continuous light
 - **Silent:** activates or deactivates silent mode
2. Briefly press the **Panic button** for:
 - **Camera:** opens the camera, takes a photo.
 - **Favourite app:** opens the preset app.

9. EMERGENCY CALL FUNCTION


Your phone has an emergency call function that you can tailor to your specific needs.

1. Make sure the **Panic Button** is set to **Emergency call**.
2. Swipe a finger across the home screen from left to right to go to the **Personal screen**. Tap on **Emergency call**.
3. Save your personal emergency contacts.
4. Do not enable the **Emergency system** until you have specified your emergency contacts.



i Important! If you do not have any emergency contacts saved, have no credit on your prepaid phone card or have no reception, the European emergency number 112 will be dialled when the enabled button is pressed. This will put your call through to the nearest police station. emporia does not assume liability for any costs incurred through you calling such an institution by mistake.

› How do I make an emergency call?

Press and hold the **Panic button**  on the back of the phone for 3 seconds.

› How do I stop an accidental emergency call?

1. If you've started an emergency call by mistake, press the red key for 3 seconds to hang up. This will interrupt the emergency call cycle.
2. Next, turn the phone off and on again to restore your emergency call status settings.

› How do I save an emergency contact?

1. Open 'Emergency call settings'.
2. Select an empty position.
3. The list of your contacts will open. Tap on a contact you want to be notified in an emergency.
4. Specify whether the contact is a private individual or a help organisation and also whether they should be sent an emergency call message in addition to receiving the call itself.

› What does the recipient of an emergency call have to do?

1. The emergency contact has to end the call and ring back the person in need of help. If this doesn't happen, the call will be ended automatically after 1 minute and the next emergency contact will be called.
2. The emporia phone will automatically answer the callback, re-establishing the connection to the emergency contact.



**Details of the emporia
emergency call function**

Scan QR code for more details

10. APPENDIX

- **Manufacturer:**
emporia Telecom GmbH & Co. KG
Industriezeile 36, 4020 Linz, Austria
- **Importer:**
emporia UK and Ireland Limited
Cardinal Point, Park Road,
Rickmansworth, Hertfordshire,
WD3 1RE, United Kingdom
- **Brand name:**
emporia
- **Model:**
emporiaSMART.7mini (E7m.v1)
- › **Scope of delivery**
- **Mobile phone:**
emporiaSMART.7mini (E7m.v1)
- **Battery:** AK-E7LT
- **USB cable:** USB-C/USB-C
- **SIM ejector tool**
- **User manual**
- › **Support**
- **emporia Service Centre**
service@emporiatelecom.co.uk
Monday-Friday, 1200-400 pm
- **United Kingdom · EN**
+44 1923 94 77 78
www.emporiatelecom.co.uk/
support/contact
- **Ireland · EN**
+353 0818 000 102
www.emporiatelecom.ie/
support/contact

› **Guarantee**

Your 12-month warranty period (6 months for the battery and accessories) begins when the device is handed over to you. You must be able to verify the time of the handover by providing us with the **original proof of purchase** (receipt or invoice) with the phone's **IMEI number** on. Keep these documents in a safe place. Any work or service provided under the warranty will be provided in accordance with the warranty terms and conditions in place at the time of your purchase. The warranty is only valid if original batteries supplied by emporia have been used. To the maximum extent permitted by applicable law, emporia is under no circumstances responsible for the following situations:

- Any loss of data or income
- Any special, incidental, consequential or indirect damage, regardless of how the damage has been caused

› **Declaration of conformity (DOC)**

emporia Telecom GmbH & Co. KG (Industriezeile 36, 4020 Linz, Austria) hereby declares that the **emporiaSMART.7mini (E7m.v1)** telecommunication or radio device complies with Directive:

- 1907/2006 REACH
- 2011/65/EU RoHS
- 2014/53/EU Radio Equipment Directive (RED)
- (EU) 2019/320 Caller location determination for emergency calls
- (EU) 2022/2380 Amendments to the Radio Equipment Directive
- 2023/1670/EU Ecodesign requirements
- 2023/1669/EU Energy labelling
- 2019/882/EU Barrier-free security regulations

The full text of the declaration of conformity can be viewed on this web page:


www.emporiamobile.com/doc



Eveline Pupeter
01/05/2025, Linz, Austria
emporia Telecom CEO

► Technical product details

- **Dimensions:** 147×70.5×9.3 mm
- **Weight:** 173 g
- **Battery:** Li-ion Polymer 3.85 V, 3500 mAh, 13.475 Wh (removable)
- **Power supply:**
USB-A adapter: DC 5 V, min. 15 W, max. 15 W; USB-C adapter: DC 5 V, ≤ 3 A, max. 15 W; (You can use chargers with higher power ratings, but this will not increase the charging speed.)



- **Standby time:** 190 h*
- **Call time:** 550 min*
(*The battery life can be reduced depending on network coverage and active applications.)
- **Internal antenna:**
SAR (body): 1.33 W/kg
SAR (head): 1.54 W/kg
SAR (limbs): 2.64 W/kg
- **Operating temperature range:**
-10°– +40°C
- **Wireless technologies:**
Bluetooth V5.0,
GPS+GLONASS+Beidou+Galileo,
WiFi 2.4G (802.11 b/g/n),
WiFi 5G (802.11 a/n/ac)

- **Hearing aid compatible:** M4/T4
- **Screen resolution:**
IPS 5.45" 18:9; 720×1440 px
- **Camera:** 13+0.3+2 MP (back camera)
8 MP (front camera)
- **Operating system:** Android 15
- **RAM:** 6 GB
- **Speicher (ROM):** 128 GB
- **SD Card:** < 256 GB

Frequencies

- **Bluetooth:** 2402-2480 MHz;
Transmitter power: < 0.004 W
- **Bluetooth LE:** 2402-2480 MHz;
Transmitter power: < 0.000234 W
- **2.4 G WiFi:** 2412-2472 MHz;
Transmitter power: < 0.048 W
- **5 G WiFi:** 5150-5350 MHz;
Transmitter power: < 0.017 W
- **5 G WiFi:** 5725-5850 MHz;
Transmitter power: < 0.015 W
- **GPS:** (receiver) 1.57542 GHz
- **BDS:** (receiver) 1.561098 GHz
- **GLONASS:** (receiver) 1.602 GHz
- **Galileo:** (receiver) 1.561098 GHz
- **NFC:** 13.56 MHz
- **GSM 900:** TX:880-915MHz, RX:925-960MHz; Transmitter power: < 1.538 W
- **GSM 1800:** TX:1710-1785MHz, RX:1805-1880MHz; Transmitter power: < 0.828 W
- **WCDMA Band I:**
TX:1920-1980MHz, RX:2110-2170MHz;
Transmitter power: < 0.156 W
- **WCDMA Band VIII:**
TX:880MHz-915MHz, RX:925-960MHz;
Transmitter power: < 0.201 W
- **LTE FDD Band 1:**
TX:1920-1980MHz, RX:2110-2170MHz;
Transmitter power: < 0.169 W
- **LTE FDD Band 3:**
TX:1710-1785MHz, RX:1805-1880MHz;
Transmitter power: < 0.191 W
- **LTE FDD Band 7:**
TX:2500-2570MHz, RX:2620-2690MHz;
Transmitter power: < 0.150 W
- **LTE FDD Band 8:**
TX:880-915MHz, RX:925-960MHz;
Transmitter power: < 0.207 W
- **LTE FDD Band 20:**
TX:832-862MHz, RX:791-821MHz;
Transmitter power: < 0.226 W
- **LTE FDD Band 28:**
TX:703-748MHz, RX:758-803MHz;
Transmitter power: < 0.200 W

Restriction of use

- In UK and EU, LTE/NR UE operation in band 28 is restricted to 703~736 MHz (Tx) and 758~791 MHz (Rx).
- In UK and EU, NR UE operation in band 78 is restricted to the frequency range 3400~3800 MHz.
- RF power reduction triggered by the combination of proximity sensors and receiver detection mechanisms as described in this TCF
- Wi-Fi (WLAN)
This equipment may be operated in all European countries.
The frequency range from 5150~5350 MHz is restricted to indoor use in accordance with the relevant legal requirements.

› Intended use

- This phone is robust and designed for mobile use. However, it still needs to be protected from moisture (rain, bathroom water, etc.) and heavy impacts.
- It is only designed for European network standards (AT, BE, CZ, DE, DK, ES, FI, FR, GB, HR, HU, IE, IT, NL, NO, PL, PT, SE, SI, SK, SZ, TR).
- Do not leave it where it will be directly exposed to the sun.
- This product contains magnets. It is therefore important to keep it away from objects that could be affected by the magnets, such as credit cards and implanted medical devices. If you use an implanted medical device, consult your doctor before using this product.
- Using it for any purpose other than that described above will result in damage to the product. Doing this also entails hazards such as fire, electric shocks, etc. This product must not be changed or modified, and the casing must not be opened.

› Safety instructions

- Please read all the safety information in this user guide carefully and follow the advice. This is the only way you will avoid hazards and infringements.
- Turn off your phone in hospitals and whenever you are near medical equipment. There should always be a distance of at least 20cm between a pacemaker and the phone when it is on.
- Never try to control a vehicle while holding the phone in your hand. Always comply with relevant national laws and traffic regulations.
- Turn off the phone whenever you are travelling in an aeroplane.
- The phone must be switched off whenever it is near a petrol station or other places with explosive substances.
- Never shine the LED torch in the eyes of people or animals! (Protection class 3)
- To prevent hearing impairments, do not use the phone on a high speaker volume for extended periods of time. Do not hold the phone to your ear when hands-free mode is activated or the emergency button has been pressed.
- Using a headset on a high volume can cause hearing impairments. Check the volume of the headset you are using.
- The phone and the accessories may contain small parts.
Keep the phone out of the reach of



young children.

- As a precaution, we recommend disconnecting the phone from the charger during thunderstorms.
- The mains adapter serves as a separator between the product and your mains supply. The mains supply must be close to the device and easily accessible.
- This device has been tested for typical applications where the device is carried on the body. To meet the RF exposure requirements, the minimum distance between the body, in particular the user's head, and the handset including the antenna must be 0 cm. Belt clips, holsters and similar accessories from third parties used with this device must not contain metallic components. Accessories carried on the body that do not meet these requirements may not meet the RF exposure requirements and should be avoided. Only use the device's built-in antenna or an approved antenna.
- This device complies with the essential requirements and other relevant provisions of Directive 2014/53/EU. All the important radio test cases have been written.
- Caution: Risk of explosion if the battery is replaced by the wrong type. Dispose of used batteries according to the instructions.
- The device complies with RF specifications when the device is 5 cm from the body.

› Ecodesign information

- Your device is equipped with a removable battery. Only use your device with an original battery. Although the battery can be charged and discharged hundreds of times, it will eventually wear out over time. If the talk and standby times are significantly shorter than normal, replace the battery. Please follow the relevant instructions on our website: <https://www.emporiomobile.com/> or contact our customer support by email: customercare@emporiomobile.com
- For environmental reasons, this packaging does not include a charger. This device can be charged with most USB power adapters and a cable with USB type C plug.
- You can use chargers with higher power ratings, but this will not increase the charging speed.

› Disposal

• Disposing of the packaging

The packaging and packaging aids are recyclable and should be made available for reuse.



• Disposing of the battery

Batteries should never be disposed of as domestic refuse! As a consumer you are legally required to return used batteries. They can be handed in at one of your community's local collection points or at specialist stores.




• Disposing of the device

If this product ever wears out, please don't dispose of it as domestic refuse. To ensure you don't cause damage to the environment, take it to a collection or recycling centre where used devices are processed for recycling in an environmentally friendly manner.



emporia online shop



www.emporiamobile.com

DA Der tages forbehold for trykfejl, fejltagelser og tekniske ændringer. **DE** Druckfehler, Irrtümer und technische Änderungen vorbehalten. **EN** Misprints, errors and technical changes excepted. **FI** Pidätämme oikeuden painovirheisiin, erehdyksiin ja teknisiin muutoksiin. **FR** Toutes erreurs d'impression, erreurs et modifications techniques réservées. **IT** Con riserva di errori di stampa, inesattezze e modifiche tecniche. **NL** Drukfouten, vergissingen en technische wijzigingen voorbehouden. **NO** Det kan forekomme trykkfeil, feil og tekniske endringer. **SV** Med förbehåll för tryckfel, misstag och tekniska ändringar.

PartNo: E7Mini_BDA-V1_11706-001-UK | 202508

